



Manufacturer:

Kingsbox d.o.o. Partizanska 129, 6210 Sežana Slovenia

Customer service:

Write us on *info@kingsbox.com* or send us a message through our website at *www.kingsbox.com/help*

Usage class:

Studio (S)

Designed in compliance with: ISO 20957

Warnings:

- Freestanding equipment shall be installed on a stable and levelled base

- All equipment designed with anchoring/attachement holes (e.g. rigs, racks, equipment and accessories for racks, storage pins/ shelves, etc.) should be securely screwed to the fixed ground/ wall/structure through all the designated fixing holes and with appropriate sized screws.

- Injuries to health may result from incorrect or excessive training

- Keep unsupervised children away from the equipment

Maximum training mass ⁽¹⁾: 80 kg (40kg/sleeve)

⁽¹⁾ Training mass - achieved through different means of resistance (weight plates, stacked weights, dumbbells, elastic cords, etc.), excluding user's bodyweight.

WARNING!

If the structure (rig/rack) onto which this equipment is attached, is not secured to the ground and / or to the wall, it may overturn and / or cause damage to person or object in the immediate vicinity.

The fixing bolts for wall and / or floor are not included in the package, since different types of anchor bolts must be used for differ-ent wall / floor types.









Tools needed:



















Note:

Free area around the training equipment should be >0,6m than the training area in the direction from which the equipment is accessed.



- Rollers:

Check the rollers regularly for any wear and tear and replace them if needed. It is normal for the rollers to show some run-in marks after the first use, but excessive wear may lead to improper movement of the trolley. (roller part nr. BY-040-4901)

Wire elements:

After every training check for possible damage to the wire or cable endings and replace them if needed. Do not excercise if the wire or cable endings are damaged!

- Upright:

Regularly wipe the upright pillar with a clean rag to enable smooth operation of the rollers. Rollers wear during use and can leave dust residue on the pillar's surface - wipe it away regularly.

Screws:

Check for any loose screws and tighten them